

Procedure document DFP Basket Strainer Replacement/

Procedure number CB-02-004-006

Cleaning

1. Procedure summary

This procedure outlines the method to Clean and replace the DFP basket strainers after the DAF feed pump.

1.1. Related Procedures

Polymer Station Operations CB-02-002-002
Saturation Tank Operations CB-02-005-003
DAF Operation CB-02-004-004
DAF P&ID CB-02-004-009

1.2. Procedure impacts and concerns

Safety Operate one DFP basket strainer at a time or system damage

will occur.

Failure to replace the strainers properly can result in damage

to equipment and high pressure water leakage.

The strainer housings are pressurized therefore pressure

must be released prior to opening lid.

Quality Improper strainer replacement could result in large debris

sent to the DAF and subsequently to the TA strainers.

Delivery DAF feed is sent from the DFP to the DAF via the DFP basket

strainers and failure to properly monitor the DFP strainers could result in significant down-time of the DFP feed pump.

Environmental Debris collected and removed from the DFP basket strainers

should be disposed of local trash receptacles. Any spills of material removed from the strainers needs to be cleaned up

as soon as possible.

Cost Failure to replace the strainers properly can result in

significant harvest down time.

Compliance The procedure outlined below ensures proper operations of

the DFP basket strainers and should be followed accordingly.

1.3. Responsibilities and owners

Document OwnerManage content and distributionMartin ChavezProcess OwnerResponsible for content and process validationDhawal DhondePlant ManagerResponsible for implementation and conformanceDhawal Dhonde

2. Process

2.1. Process description

The purpose of this SOP is to describe procedures for cleaning the DFP basket strainers.

Revision: R2



2.2. Process diagram



2.3.1 Process Steps

- 2.3.1. DFP basket strainer removal
 - 2.3.1.1. During a harvest run the pre-strainer pressure gauge will monitor the pressure at the inlet to the basket strainers. When the inlet pressure goes over 10 psi the basket strainer needs to be changed.
 - 2.3.1.2. If DFP basket strainer 03-F-2900A (circled in diagram) needs to be changed, open valves AH-V703 and AH-V704 to allow flow to go through 03-F-2900B (figure 1).




Figure 1. DFP Basket Strainer diagram.

2.3.1.3. Close valves AH 701 and AH-702 to stop flow to the clogged 03-F-2900A strainer (figure 2).

Note: Flow will go through both strainers for a period, NEVER close off both strainers simultaneously during harvesting. Line will pressurize and DFP pump damage can occur.


Note: Valves AH701 and AH702 work together to manage flow through 03-F-2900A

Note: Valves AH-703 and AH-704 work together to manage flow through 03-F-2900B

Page 2 of 6

Revision: R2





Note: Do not switch valves back into original configuration, the filters are meant to operate in an A-B fashion where only one is active at any one time. This allows for the filters to be switched and cleaned without any down time in the system.

Figure 2. DFP Basket Strainer area.

2.3.1.4. Open the pressure relief valve at the bottom of the clogged strainer housing as seen figure 3.



Figure 3. Pressure relief valve under strainer housing.

2.3.1.4. After opening the relief valve under the basket strainer housing, ensure that the pressure is being relieved (figure 4).

Note: If DFP basket
strainer 03-F-2900B needs
to be changed, open valves
AH-V701 and AH-V702 to
allow flow to go through
03-F-2900A, close valves
AH-V703 and AH-V704, and
follow process steps
outlined for said strainer
and valves.





Figure 4. Fluid running out of relief line.

2.3.1.5. Loosen and remove nuts securing strainer lid. Using crescent wrench located near strainer lid. Figure 5



Figure 5. Nut removed example


Note: If housing pressure persists when loosening nuts, re tighten nuts and contact your team lead/supervisor.



Figure 6.

2.3.1.6 Open lid using hoist. (Figure 6)

2.3.1.7. Slide the hoist over to the basket strainer and clip the hook to the basket strainer. (Figure 7).





Note: You may have to work the up and down

button as you work the strainer out of the strainer

Note: When lifting lid with hoist be careful not to pull lid too high. Damage to lid

housing guide.

hinges can occur.





Figure 7. Winch hooked onto strainer

2.3.1.8. After the hook is secured and in place, slowly work the basket strainer out of the strainer housing using hoist.

2.3.2. Cleaning strainer

- 2.3.2.1. Slide the basket over to the end of the concrete pad near the water hose.
- 2.3.2.2. Lower the strainer to the ground and lean the mouth of the strainer towards/facing the ground.
- 2.3.2.3. Using the water hose, wash the debris off of the strainer from the back side of the strainer basket (figure 8).



Figure 8. Winch hooked onto strainer

2.3.3. DFP basket strainer re-install

- 2.3.3.1 Lift the strainer up to the top of the hoist and slide the basket back until the strainer is directly above the basket strainer housing.
- 2.3.3.2. Lower the strainer into the housing and ensure the bottom of each end of the basket strainer slides into the guide rails (See Figure 9).



Figure 9. Insert strainer using rail guides.

- 2.3.3.3. Remove the hoist clip from the strainer,
- 2.3.3.4. Lift and slide the hoist back out of the way.

Revision: R2

Procedure document DFP Basket Strainer Replacement/ Cleaning

Procedure number CB-02-004-006

- 2.3.3.5. Check lid O-ring for damage or extreme wear
- 2.3.3.6. Lower the lid and ensure that the lid fit evenly around the strainer basket.
- 2.3.3.7. Place bolts back over into place and tighten bolts in a tightening sequence as shown in figure 10.




Figure 10. Tightening sequence.

2.3.3.8. Record time and pressure the filter was cleaned on the harvest record hourly data sheet.

3. Required documents

3.1. Input documents

Harvest Record Hourly Data Sheet

L:\Harvest\Harvest Records

3.2. Output documents

Harvest Record Hourly Data Sheet

L:\Harvest\Harvest Records

4. Document control

4.1. Revision history

RO – Initial Release – Timothy Langer	March 23, 2012
R1 – Updated procedure – Marcos Delgado	September 5, 2012
R2 –Juan Enriquez	December 12, 2013
R3 – Tony Matsumoto	December 10, 2013
R4- Leo Willis, Melena Pacheco	November 19,2014
R4- Martin Chavez	January 12,2015

4.2. Document approval

<Name> <Approval date>

4.3. Document reviewers

<Name>> <Last reviewed date>

5. Risk analysis

<Risk name> < Mitigation plan>

Revision: R2